Thank you for your purchase of R&S®ELEKTRA! The following is a startup guide for installing R&S®ELEKTRA the first time

Setting up the hardware

Detach SIM card



- 2 a. Open the SIM card cover from the back of the reader
 - h Insert SIM card with the non-angled corner first into the reader. Make sure that the chip faces downwards.
 - c. Close the SIM card cover back to the reader



3 Connect to USB port on PC



Installing R&S®ELEKTRA

- 1) Go to the download page www.rohde-schwarz.com/software/elektra.
- Click on the download link for FLEKTRA.
- Save the installation file to a location on your PC.
- Double click on the downloaded file to start the installation.



- Follow the instructions on the screen
- R&S°ELEKTRA icon / should now appear on the desktop.
- Double click on the ELEKTRA icon 5 to launch R&S°ELEKTRA.

A comprehensive user manual is available in R&S®ELEKTRA. For more information and other application notes. please go to www.rohde-schwarz.com/product/elektra

Rohde & Schwarz GmbH & Co. KG

Europe, Africa, Middle East I +49 89 4129 12345 North America | 1 888 TEST RSA (1 888 837 87 72) Latin America I +1 410 910 79 88

Asia Pacific I +65 65 13 04 88 China | +86 800 810 82 28 | +86 400 650 58 96

www.rohde-schwarz.com

www.rohde-schwarz.com/support

The R&S°ELEKTRA Test Software contains open source software packages.

Copies of the respective licenses are included in the 'R&S®ELEKTRA Test Software Open Source Acknowledgement '.

- Please refer to the Download / Software area www.rohde-schwarz.com/software/elektra.

R&S® is a registered trademark of Rohde & Schwarz GmbH & Co. KG Trade names are trademarks of the owners

5601.0501.02 | R&S®ELEKTRA

© 2024 Rohde & Schwarz GmbH & Co. KG | Mühldorfstr. 15, 81671 München, Germany