

# Coverage Measurement on 5G NR Network

[didier.pertuis@rohde-schwarz.com](mailto:didier.pertuis@rohde-schwarz.com)



COMPANY CONFIDENTIAL


# What is 5G NR?

## Triangle of use-cases

### Massive IoT

- | A diverse ecosystem (operators, manufacturers, local authorities, certification only for some technologies)
- | Mix of technologies (GSM, Lora, Zigbee, Cat M, NB-IoT,...)
- | **It's all about cost efficiency and massive connectivity**

eMBB  
Enhanced  
mobile broadband



Massive IoT

Ultra reliable &  
low latency  
communication

### eMBB – the known playground


- | Established ecosystem (operators, manufacturers, certification of devices)
- | Evolution from existing technologies (LTE-A, 802.11 ad) and revolutionary additions (cm- / mm-wave)
- | **It's all about data (speed and capacity)**

### URLLC

- | A significantly enhanced and diverse ecosystem (operators, manufacturers, verticals, certification not existing (yet))
- | Existing technologies do not provide sufficient performance
- | **It's all about reliability and security (data and capacity)**

# The spectrum challenge...

- | Especially eMBB (enhanced mobile broadband) and Massive IoT needs new spectrum for to cope with the increasing data consumption and number of connected devices
- | 5G NR is divided in sub 6 GHz and mm-wave band




# Frequency trends for 5G

## NR frequency range 2 Reserved numbers 257-512

	Downlink	Uplink
n257	26.5 – 29.5 GHz	26.5 – 29.5 GHz
n258	24.25 – 27.5 GHz	24.25 – 27.5 GHz
n259	n/a	n/a
n260	37 – 40 GHz	37 – 40 GHz

## NR frequency range 1 reserved numbers 65-256

	Downlink	Uplink
...	...	...
n77	3.3 – 4.2 GHz	3.3 – 4.2 GHz
n78	3.3 – 3.8 GHz	3.3 – 3.8 GHz
n79	4.4 – 5.0 GHz	4.4 – 5.0 GHz
...	...	...



# 5G NR spectrum utilization

## Dual connectivity, for Non-Standalone (NSA) mode operation

- Two band combinations (2CC) of 1CC in NR band and 1CC in LTE band
- Additional tables for three band (3CC), four band (4CC) and five band (5CC) in TS38.101-3

Source: TS38.101-3

		LTE frequency bands																		
		1	3	5	7	8	11	18	19	20	21	25	26	28	38	39	41	42	66	71
5G NR frequency ranges	n7 (FDD 700MHz)		█																	
	n28 (FDD 2.6GHz)	█	█		█					█										
	n41 (TDD 2.6 GHz)											█	█				█			
	n71 (FDD 600MHz)																		█	█
	n77: 3.3 – 4.2 GHz	█	█			█	█	█	█		█		█	█			█	█		
	n78: 3.3 – 3.8 GHz	█	█	█	█	█	█	█	█	█		█	█	█	█	█	█	█		
	n79: 4.4 – 5 GHz	█	█			█	█	█	█		█		█	█		█	█	█		
	n257: 26.5 – 29.5 GHz	█	█	█	█	█	█	█			█		█	█			█	█	█	
	n258: 24.25 – 27.5 GHz		█		█	█									█		█	█		

# 5G New Radio (NR) offers a flexible air interface

## Summary of key parameters


**Changed to 7.125 GHz**

Parameter	FR1 (450 MHz <del>– 6 GHz</del> )	FR2 (24.25 – 52.6 GHz)
Carrier aggregation	Up to 16 carriers	
Bandwidth per carrier	5, 10, 15, 20, 25, 30, 40, 50, 60, 80, 90, 100MHz	50, 100, 200, 400 MHz
Subcarrier spacing	15, 30, 60 kHz	60, 120, 240 (not for data) kHz
Max. number of subcarriers	3300 (FFT4096 mandatory)	
Modulation scheme	QPSK, 16QAM, 64QAM, 256QAM; uplink also supports $\pi/2$ -BPSK (only DFT-s-OFDM)	
Radio frame length	10ms	
Subframe duration	1 ms (alignment at symbol boundaries every 1 ms)	
MIMO scheme	Max. 2 codewords mapped to max 8 layers in downlink and to max 4 layers in uplink	
Duplex mode	TDD, FDD	TDD
Access scheme	DL: CP-OFDM; UL: CP-OFDM, DFT-s-OFDM	

# Managing the key challenges related to 5G NR RAN

## New spectrum


- Even 3.5 GHz is different from today's frequencies



- What about coverage?
- Spectrum clearance?

## Beamforming and massive MIMO

- How many beamforming ?




## Flexibility of air interface and gNB configuration

- Bandwidth:  
5, 10, 15, 20, 25, 30, 40, 50, 60, 80, 100 MHz (FR1)  
50, 100, 200, 400 MHz (FR2)
- Subcarrier Spacing:  
15, 30, 60 kHz (FR1)  
60, 120, (240) kHz (FR2)
- Mapping onto antenna ports:  
single beam / multi beam sweeping

➤ **New technology elements drive the need for (and complexity of) 5G NR network measurements**

# Architecture Evolution – DC Options

Option 3 is priority 1 in 3GPP, followed by Option 2






# How will the 5G UE (NSA mode) get the SSB?

Network instructs UE to carry out signal quality measurements

Let's see what's around?

UE is instructed via LTE RRC to carry out signal measurement on 5G NR carriers

Quality measurements  
Synchronization  
(B)  
SSBs?  
Configuration?




```
DL DCCH Message
├─ _DL_DCCH_Message message: c1
├─ rrcConnectionReconfiguration 2
│   └─ rrc_TransactionIdentifier 1
├─ criticalExtensions c1: rrcConnectionReconfiguration_r8
│   └─ measConfig: 18
│       └─ measObjectToAddModList 2
│           └─ _MeasObjectToAddMod
│               └─ measObjectId 1
│                   └─ measObject measObjectEUTRA: 16
│                       └─ carrierFreq 547
│                           └─ allowedMeasBandwidth (0) mbw6
│                               └─ presenceAntennaPort1 (0) false
│                                   └─ neighCellConfig (0x02) '10'B
│                                       └─ neighCellConfig[] (2) The MBSFN subframe allocations of all neighbour cells are identical to or subsets of that in the serving cell
├─ _MeasObjectToAddMod
│   └─ measObjectId 2
│       └─ measObject measObjectNR_r15: 10
│           └─ carrierFreq_r15 647040
│               └─ rs_ConfigSSB_r15 (2) _RS_ConfigSSB_NR_r15
│                   └─ measTimingConfig_r15 (2) _MTC_SSB_NR_r15
│                       └─ periodicityAndOffset_r15 sf20_r15: 18
│                           └─ ssb_Duration_r15 (4) sf5
│                               └─ subcarrierSpacingSSB_r15 (1) kHz30
│                                   └─ quantityConfigSet_r15 1
│                                       └─ Extension_Addition_Group : bandNR_r15
│                                           └─ setup 78
```


```
-- ASN1START
measObjectNR-r15 ::=
carrierFreq-r15
rs-ConfigSSB-r15
threshRS-Index-r15
...
maxRS-IndexCellQual-r15
offsetFreq-r15
blackCellsToRemoveList-r15
blackCellsToAddModList-r15
quantityConfigSet-r15
...
}
```

# What did we measure in LTE?

## Synchronization and reference signals („LTE narrowband“)




## 5G NR ARFCN as in LTE.....




NR-ARFCN: NR absolute radio frequency channel number

5G NR ARFCN as in LTE.....BUT not so simple..... 😊




NR-ARFCN: NR absolute radio frequency channel number

# 5G NR channel raster vs SSB raster




# What can we measure?

## 5G NR carrier overview



# What can we measure?

## 5G NR SSBlocks





# Why are SSB measurements essential?

- | The UE / CPE uses the SSB for 5G NR cell search and synchronization
- | The UE measurements on the different SSBs are essential to determine the right beam configuration for data transmission (based on an UE / CPE / gNB internal algorithm)
- | The SSB is always there (at least once per 5G NR carrier) and the sequence is known
- | Therefore it's perfect for
  - coverage measurement
  - CIR measurement
  - Interference measurement
  - Beamforming evaluation





# Let's zoom into a SSB...

## Zoom factor 1




Let's zoom into a SSB  
Zoom factor 2



DM-RS PBCH  
PSS PBCH SSS PBCH  
DM-RS PBCH


# How often is the SSB block transmitted (time domain)?

SSB Transmission time domain pattern: **SSB periodicity**



Let's zoom into the picture...

Case A  
Below 3 GHz  
SCS= 15 kHz  
L=4




# What is a „case“?

- I A „case“ defines the max. number of SSB transmissions (L) and the SSB subcarrier spacings for several 5G NR bands
- I It also defines the start-OFDM symbols of each SSBLOCK
- I 3GPP includes a look-up table, which might change from release to release

SSB Mapping TS 38.213


Subcarrier Spacing	OFDM Symbol (s)	f ≤ 3 GHz	3 GHz < f ≤ 6 GHz	6 GHz < f
Case A : 15 kHz	(2,8) + 14n	n = 0,1 s = 2,8,16,22 L = 4	n = 0,1,2,3 s = 2,8,16,22,30,36,44,50 L = 8	
Case B : 30 kHz	(4,8,16,20)+28n	n = 0 s = 4,8,16,20 L = 4	n = 0,1 s = 4,8,16,20,32,36,44,48 L = 8	
Case C : 30 kHz	(2,8) + 14n	n = 0,1 s = 2,8,16,22 L = 4	n = 0,1,2,3 s = 2,8,16,22,30,36,44,50 L = 8	
Case D : 120 kHz	(4,8,16,20) + 28n			n=0, 1, 2, 3, 5, 6, 7, 8, 10, 11, 12, 13, 15, 16, 17, 18 L = 64 s=4, 8, 16, 20, 32, 36, 44, 48, 60, 64, 72, 76, 88, 92, 100, 104, 144, 148, 156, 160, 172, 176, 184, 188, 200, 204, 212, 216, 228, 232, 240, 244, 284, 288, 296, 300, 312, 316, 324, 328, 340, 344, 352, 356, 368, 372, 380, 384, 424, 428, 436, 440, 452, 456, 464, 468, 480, 484, 492, 496, 508, 512, 520, 524
Subcarrier Spacing	OFDM Symbol (s)	f ≤ 3 GHz	3 GHz < f ≤ 6 GHz	6 GHz < f
Case E : 240 KHz	(0, 12, 16, 20, 32, 36, 40, 44) + 56n			n=0, 1, 2, 3, 5, 6, 7, 8 L = 64 s=8, 12, 16, 20, 32, 36, 40, 44, 64, 68, 72, 76, 88, 92, 96, 100, 120, 124, 128, 132, 144, 148, 152, 156, 176, 180, 184, 188, 200, 204, 208, 212, 288, 292, 296, 300, 312, 316, 320, 324, 344, 348, 352, 356, 360, 372, 376, 380, 400, 404, 408, 412, 424, 428, 432, 436, 456, 460, 464, 468, 480, 484, 488, 492

Case A  
Below 3 GHz  
SCS= 15 kHz  
L=4



# What happens in the field?

Case A  
Below 3 GHz  
SCS= 15 kHz  
L=4




| Each SSB transmission in the time domain means „switching the SSB index / switching beams“ if configured by the network

| **Each SSB has a SSB index**


# Signals for Beamforming

- | **Single Beam** and **Multi Beam** scenarios supported in 5G NR
- | SS Block Index is used to separate SSB transmission on different Beams
- | Mapping of Antenna ports and Physical Beams to the SSB Index is implementation specific, e.g. will/can differ between vendors

## Single Beam



## Multi Beam




# Which parameters do we get from the 5G NR SSB ?

- I Cell / SSB identification
  - PCI
  - SSB index
  - GSCN (from configuration)
  - SSRef (from configuration)
- I RSSI measurements
  - Inband Power / SSB RSSI
- I Secondary sync measurements
  - SSS-RSRP
  - SSS-RSRQ
  - SSS-SINR
  - SSS-Pathloss (if configured!!)
- I Primary sync measurements
  - PSS-RSRP
  - PSS-SINR
  - PSS-Pathloss (in configured!!)

- I DM-RS measurements (DM-RS included in PBCH)
  - DM-RS-RSRP
  - DM-RS-SINR
  - DM-RS-Pathloss (if configured!!)
- I PBCH measurements
  - PBCH-RSRP
  - PBCH-SINR
  - PBCH-Pathloss (if configured!!)
- I Secondary sync and PBCH measurements
  - SSS-PBCH-RSRP
  - SSS-PBCH-SINR
  - SSS-PBCH-Pathloss (if configured!!)
- I Primary and secondary sync and PBCH measurements
  - xSS-PBCH-RSRP
  - xSS-PBCH-SINR
  - xSS-PBCH-Pathloss

- I CIR parameters based on SSS
  - Max. delay of the peaks Time delta between first and last arrived peak
    - Power
    - Ptotal



DM-RS PBCH  
PSS PBCH SSS PBCH  
DM-RS PBCH


# Coverage Measurement on 5G NR Network

- What do we measure ??



# What happens during a drive test?


- | During a drive test we cross several PCIs and several SSB indices belonging to certain PCIs
- | Each beam / SSB is described by a SSB index and PCI



# 5G NR ACD Helpful Tools


supports sub 6 and mm-wave frequency bands

- | The 5G NR ACD starts with a fast spectrum sweep (grey lines in the ACD view) a 5G NR SSB is visualized using a blue marker in the ACD view



# ROMES Top N Pool Basics

## 5G NR Scanner TEC settings



### Beam specific Top N Pools

#### Beam Quality Ranking

- Top 1 SSB Index @ PCI
- Top 2 SSB Index @ PCI
- Top 3 SSB Index @ PCI
- ...

### Cell specific Top N Pools

#### Cell Quality Ranking

- Top 1 PCI
- Top 2 PCI
- ...
- ...

# 5G NR Scanner Top N View

## Beam specific Top N Pool

5G NR Scanner TopN View:1 R&S 5G NR Scanner (TSME)[1]

Top N: Beam RSRP


Color	#	SSB-Ref	SS-Ref
Red	1		3749.80
Green	2		3749.80
Blue	3		3749.80

**Beam specific  
Top N Pools**

- Ranking of TopX Best beams (SSB Indices)
- Example of TopN Pool rank based on SS-RSRP
- TopX Beams can belong to different PCIs!

# 5G NR Scanner Top N View


## Cell specific Top N Pool



**Cell specific  
Top N Pools**

- Ranking of TopX Best Cells
- SSB Index for qualified Beams used in the Cell Quality averaging
- SS-RSRP, SS-SINR and SS-RSRQ values are cell averages

# Multi Beam Example in ROMES




5G NR Scanner TopN View:1 R&S 5G NR Scanner (TSME)[1]

Top N: SSB RSRP

Top N List

Color	#	TopX	▲	PCI	SSB Idx	Power	SS-RSRP	SS-SINR	SS-RS...	GSCN	SS-Ref
	1	1		15	0	-65.3	-75.0	-9.1	-19.9	---	3749.80
	2	2		15	2	-67.1	-76.6	-9.0	-19.9	---	
	3	3		15	3	-77.7	-89.0	-10.9	-21.5	---	
	4	4		13	7	-87.7	-96.5	-8.2	-19.2	---	
	5	5		15	1	-83.6	-96.8	-12.9	-23.5	---	
	6	6		15	4	-82.6	-94.4	-11.6	-22.2	---	
	7	7		13	6	-86.5	-95.9	-8.8	-19.6	---	
	8	8		15	5	-83.4	-97.4	-13.8	-24.3	---	


Top N Chart (Click to open)



Cell Color by PCI

Beam Color by SSB Index

# Single Beam Example



5G NR Scanner TopN View:1 R&S 5G NR Scanner (TSME)[1]


Top N: SSB RSRP

Top N List

Color	#	TopX	▲	PCI	SSB Idx	Power	SS-RS...	SS-SI...	SS-RS...	GSCN	SS-Ref
	1	1		20	0	-63.1	-66.1	-0.1	-13.3	---	3500....

Top N Chart (Click to open)

One PCI and SSB index detected




# 5G NR scanner SSB History View

History of TopN [1..X] Cell and [1..Y] Beam (SSB Idx) identities over time

Cell specific Top N Pools

Configured Top N Pools



1st Best cell

2nd Best cell

→ t




# 5G NR scanner SSB performance view

Background color: PCI

Bar color: SSB index

By default: 1st best and 2nd best cell is shown




- | Most detailed view to analyze cell and SSB coverage over time
- | Compare with UE: was the UE on the best channel/cell/beam when doing RACH?
- | When driving through the beam coverage of a cell: Are all beams transmitted as expected?

# 5G NR UE Measurement

5G NR Cell

5G NR Uplink

5G NR Downlink



5G NR Cell History

5G NR Cell Quality


RSRP, RSRQ

Tx Power

DL Thp


# Coverage

- **Expected UE sensitivity:**  
**~ -120 dBm (SS-RSRP)**
- **Surprisingly good SSB coverage in suburban area**



# SSB / beam ranking

- **SSB / beam index visualized on the map**



# Coverage Measurement on 5G NR Network

- How do we measure ??




# ROMES Solution for 5G NR Measurement

- | ROMES based on TSME6 / TSMA6 Scanner + 5G NR UE
- | Laptop / Shoulder bag / Backpack



# Setup for 5G NR measurements including Sub6 and mmW

# Setup for a Sub6 and mm-Wave measurement





# 5G NR measurements – use cases and antennas

## mm-wave measurement with FR4 backpack



TSME-Z20: omnidirectional mm-wave antenna

<b>Frequency</b>	26 to 40 GHz
<b>Connector type</b>	K type jack
<b>Power Handling</b>	10 Watt c.w.
<b>VSWR</b>	< 2.0:1
<b>Gain</b>	2 to 4 dBi
<b>Azimuth Ripple</b>	+/- 1 dB worst case, generally < +/- 0.5 dB
<b>Weight</b>	40 g
<b>Size- max.</b>	46 mm diameter
<b>Mounting</b>	Three M2.5 screws equispaced on 39.5 mm pitch circle diameter.
<b>Construction</b>	Aluminium and Engineering plastics



FR4 backpack

Thank you

